

Dumbwaiter Model: ☐Mezz-100	☐ Mezz-200
Have you contacted your local code enforcement for safety requirements? Is there living space below the dumbwaiter shaft? Where did you hear about us?	Yes No Yes No
Triffic and you floar about us.	

1-800-409-5438 ~ 530-333-1953

ob	or Business Name:
ont	ractor's Name, Phone #, & Email:
hip	to address: Is the "Ship To" address a commercial location? Yes No
	Illation address:
	ers' Name & Phone #
VVI I	*Owners' information is for warranty records only. Powerlift does not contact the owner. Powerlift does not install or service dumbwaiters.
1.	The finished floor to finished floor measurement:
2.	The maximum height of shaft: ( The distance from the bottom floor to the ceiling of the top floor.)
3.	The desired loading height. bottom floor: top floor: top floor: (Usually 36", this is the height above the floor where the dumbwaiter car will stop.)
4.	Locating the openings:  While standing where the bottom floor opening will be, as if you were loading it, is the top floor opening on the same side as the bottom floor opening, or is it to the left, right, or back?  □ Same side as downstairs □ Left □ Back □ Right
5.	Locating the door handles: While facing each opening, which side of the hoistway door will the door handle be on?  Bottom floor: ☐ Left side ☐ Right side ☐ Top floor: ☐ Left side ☐ Right side
6.	Locating the push buttons:  While facing each opening, which side of the hoistway would you like the push buttons mounted to? (They can't be mounted to the front of the unit and are usually mounted on the handle side.)  Bottom floor: ☐ Handle side ☐ Hinge side ☐ Hoor: ☐ Handle side ☐ Hinge side  Height above the floor: ☐ (Usually 48")
7.	Desired voltage for the mezzanine lift: ☐ 110 V ☐ 220 V
8.	Dumbwaiter cars come with a 3" Lip. No Lip requires a car gate.
	□ 3" LIP □ NO LIP
9.	Accessories / Special Instructions: